

Vent-Axia®

Window kit fitting instructions.

To suit window kits 442947 (Centra & Silhouette 100) and 443234 (VA100).

This kit can accommodate glazing holes of between Ø110mm and Ø140mm. We recommend a Ø115mm hole.

Without the loose spacer supplied in the kit, glazing thicknesses of between 17mm and 43mm can be accommodated. Use the extra spacer on the outside for thinner windows (down to 4mm).

1. Break out the blank in the top of the internal spacer to create a Ø10mm hole.
2. Fit the supplied grommet in the hole.
3. Stick one gasket to the back of the internal spacer.
4. Decide whether you need to use the extra spacer supplied (see above).
5. If you do need the spacer, push it on to the back of the external grille assembly.
6. Stick the second gasket on to the back of the external grille assembly.
7. From the outside, push the spigot of the external grille assembly through the hole in the glass, making sure the grille is the correct way up. The louvers should tilt downwards to prevent rain getting in.
8. From the inside, offer the internal spacer up to the spigot of the external assembly, making sure the cable clamp is at the top, and screw the ring up until it is done up tight.
9. Fit your power cable through the grommet and secure it using the cable clamp provided.
10. Remove the front cover of the fan and offer it in to position.
11. Bring the end of the power cable through the hole in the back of the fan.
12. Screw the fan to the window kit using the fixing screws supplied with this kit.
13. Make your electrical connections following the fan's instructions.
14. Replace the cover.

